

Steps to remove RT240 cover

Setp 1: Get your RT240 and screwdriver ready



Step 2: Unscrew the screws on the bottom



Setp 3: Pull out the cover and scanner



Setp 4: Take them apart with a little effort



* Setp 5: Finally screw on the bottom screw and done

Steps to Install RT240 cover


Setp 1: Use a small tool to pry open the RT240




Setp 2 : Take them apart with a little effort



Setp 3: This is in a fully disassembled state




Setp 4: Install the cover first, and align the holes.



Setp 5:Put on the orange shell



Setp 6:Press it with your fingers to immobilize it



Setp 7: Screw in the screws and done

