



QUICK USER GUIDE

2D Handheld Scanner

RT630



Thanks for choosing this scanner!



RTscan Technology Limited | website: www.rtscan.net

Tel: +86755 23762089 E-mail: sales@rtscan.net

Technical Support: support@rtscan.net



Enter setup

Use the setup code

Read "Enter Setup" bar code to activate the setup code function. Read 'Exit Setup' to exit the setup code function This is necessary before reading any setting code, or-else the setup will not work.



@SETUPE1
Enter Setup



Exit setup



USB CDC (Virtual Com)



USB HID (Keyboard simulation)

Exit Setup



Enter setup



Keyboard layouts vary from country to country. The default setting is U.S. keyboard.



** U.S. (English)



Belgium



Brazil



Canada (French)



Exit Setup



Enter setup





Czechoslovakia



Denmark



Finland (Swedish)



France



Enter setup

Germany/Austria



Greece



Hungary



Israel (Hebrew)





Exit Setup



Enter setup







Italy



Latin America/South America



Netherlands (Dutch)



Norway



Poland



Portugal



Romania



Russia



NSETLIDE∩

Exit Setup



Enter setup







Slovakia



Spain



Sweden



Switzerland (German)



Türkiye_F



Türkiye_Q



UK



Japan







Exit Setup



Enter setup

Scan Mode

Trigger Mode: Press the scan button to activate a decode session. The decode session continues until a barcode is decoded or you release the trigger.

Sense Mode: The engine activates a decode session every time it detects a barcode presented to it. The decode session continues until a barcode is decoded or the decode session timeout expires.



** Trigger Mode



Sense Mode

Indicator LED

The power on blue always on when powered, and blue flash once when the decoding success.

Buzzer

Power On beep once. Good Read beep once.

Exit Setup



Enter setup



Carriage return/Line feed



**Enable

Read 'Enable' to add carriage return/line feed pair (CRLF)



Disable

Read 'Disable' to disable carriage return/line feed pair (CRLF)



Exit Setup



Enter setup

Factory default setting

All the scanners have a factory default setting. Read "Load Factory Default Setting" barcode and all the attributes of the scanner will be restored to ex-factory status.

You are most probably to use this barcode under the following conditions:

- The scanner setting has an error, you are unable to read the barcode.
- You have forgotten what type of settings you have made to the scanner previously, yet not wishing to be influenced by the previous settings.



Load factory default setting

For more setting codes, please scan below bar code to visit the website.



Exit Setup



Table for Names and Content Identification of Toxic and Hazardous Substances in this Product

	Part Name	Toxic or Hazardous Substances and Elements									
		Pb	Hg	Cd	Cr(VI)	РВВ	PBDE	DEHP	DBP	ВВР	DIBP
	Structural	0	0	0	0	0	0	0	0	0	0
	Packaging	0	0	0	0	0	0	0	0	0	0

- O: indicates that the content of the toxic and hazardous substance in all homogeneous materials of the component is below the limit specified in RoHS Directive 2011/65(EU) with amendment (EU) 2015/863
- X: indicates that the content of the toxic and hazardous substance in at least one homogeneous material of the component exceeds the limit stipulated in RoHS Directive 2011/65(EU) with amendment (EU) 2015/863

However, as for the reason, because there is no mature and replaceable technology in the industry at present.

The products that have reached or exceeded environmental protection service life should be recycled and reused according to the Regulations on Control and Management of Electronic Information Products, and should not be discarded randomly.